


Connection diagram / Anschlussplan / Plan de raccordement / Aansluitschema / Schemat podłączenia



Contact failure Störmeldung kontakt Contact défaut Storingscontact Styk Usterka	
Tanner MDA 121L EC Tanner MDA 131L EC Tanner MDA 141L EC	Not present Nicht vorhanden Indisponible Niet aanwezig nieobecny
Tanner MDA 211H EC Tanner MDA 221H EC Tanner MDA 231H EC Tanner MDA 241H EC	TK TK
Tanner MDA 311L EC Tanner MDA 321L EC Tanner MDA 331L EC Tanner MDA 341L EC	2A - 250Vac 3A - 30Vdc
Tanner MDA 411L EC Tanner MDA 421L EC Tanner MDA 431L EC Tanner MDA 441L EC	COM NC NO 2A - 250Vac 3A - 30Vdc

WS - Isolator switch (option)
Reperaturschalter (Wählbar)
L'interrupteur de proximité (facultative)
Werschakelaar (optioneel)
Wylacznik serwisowy (Optional)



Tanner MDA EC

Schema nummer				T-015000-EU				←
Get.	J.W.	Datum	1-2-2018	Groep	TANNER	Type	MDA-EC	→
Gec.		Norm		Art.nr	[H]	Versie	1.0	